









Pronto

wonen


MODEL:ZUCCONI PDC-4082A




ASSEMBLY INSTRUCTION

A	B	C	D	E	F		
							
M4	x1	M6*40	x4	M6*35	x4	M5	x1
							x2

STEP 1



STEP 2



STEP 3

